

# Service visit to NEAR

10/6/13

Tom is at NEAR to reboot the rad mote, and replace the dessicant in the radiometers.

He arrived at 3:55 pm.

Yellow light in center of radiation and SPN1 mote boards were both on, although both were sampling data (flashing red light). He power cycled both motes, which were not coming in. Rad mote is ID8.

Replacing dessicant at 04:04. Replaced pyranometer dessicants, but did not know how to access pyrgeometers (square dessicant holder).

Left at 4:11.