

## tnw02 initial install

About 13:30, we powered up tnw02. Due to rain (and forgetting 2 screws), we only installed the NR01 and the soils about 45min later. These are now reporting. When the rain abates, we'll add the sonics and TRHs. Soil core taken during installation, as usual.