

Wslope6 site visit Jan 6, 2011

6 Jan Oncley@Dong

About 10cm of snow on the ground

0953 klean krypton 1.0 -> 2.5V

1003 clean up radiometers

1012 soil samples (top 4cm is frozen, therefore samples represent depths closer to 0-4cm and 4-6cm)

1028 add Tsoil sensors

1030-1034 break ice in the gauge

1038 shoot the booms: sonic 79.0; prop 169.3

1038 take pictures

1046 add about 0.6galloons of ETI fluid 3 to gauge