## site hiland3 visit

11 Jan, 2011 On site: John and Ling

1305 clean up radiometers

1338 change the desiccants for the radiometers (2 long and 1 short, the upper right long doesn't need to change)

1356 add the third battery, and add insulation to the battery box to keep them warm (batt-dsm measured 14.44V)

1358 rain gauge, ice blogs