

site eslope5 visits

11 Jan , 2011

1450-1605

1459: clean up radiometers,

15:45 change and add desiccants for the lower two radiometers

1545: add third battery, and add insulation

1600: turn off wifi

notes: radiometers:

significant trampling of snow on the south side of the saddle horse. prefer one trail from north to the stand. All others will be outside of the fence.