

## Downwind-2 serial board stopped

The serial board on downwind-2 adam stopped around 17:10, July 5. Restarted around 17:40.