

Replaced sonic 2b (SN 1117) with 13b (SN 0741).

After the reconfiguration, sonic 2b (s/n 1117) would not start operating. We replaced it with the sonic previously used at 13b (s/n) 0741. For configurations 2 and 3 we are using a [matching sonic from the profile tower](#) for sonic 13b, i.e. the 3m and 7m sonics.