

downloading pocketecs and usb drives

To download data from a pocketec or usb pen drive, do the following:

1. Plug the drive into the 1 spare port on the isff system (latitude D830)
2. On isff, do

```
copy_usbdisk.sh AHATS
```

3. When it finishes, power down the pocketec and remove.

It copy_usbdisk.sh reports errors, then you should do a complete bad block check of the drive. Insert the drive in isff, and do:

```
bb_fsck.sh
```

The bb_fsck.sh command takes about 5 hours to complete on a 60 Gbyte pocketec.