

## site 2 trh

I have noticed that at site 2 on two separate occasions, when power to DSM is recycled, the trh data output is in hexadecimal until the sensor itself is rebooted.

moved Viper power cable to another power port on the main power board.