## config 3 dimensions

The config3 transition yesterday went:

- 1. Move the east horiz array up 3 slots. (This measured at ~4.87m for the top of 5b's boom to the base plate.) [started ~0600]
- 2. Move the west horiz array up 3 slots.
- 3. Move 6t and 6b up.
- 4. Move 12b up.
- 5. Move 5.5m and 4.3m up to ~5.8m and ~4.8m (also T/RHs) [done by 0830]
- 6. Tear-down upwind and move to staggered upwind, sequence 11u -> 3u [done by 1230]
- 7. Remove upwind bases [1530-1630]

When we started to build config 3, we measured 3.254m from the config 3 reference line to the top of 5b's boom (of course, after raising it to its position). New measurements for other sensors:

6t: 3.252m

6b: 3.250m

12b: 3.275m

(I didn't record new measurements of the 2 profile sensors.)

All of the upwind sensors were set to 3.261 = 3.254+0.7 to the top of the clamp +/-1mm.

P.S. The reference height mark #3 is 15.2cm below the mark for #2.

P.P.S. Some spacings:

5t 133.4cm 6t 127.4cm 7t

5b 133.7cm 6b 127.8cm 7b

11b 128.3cm 12b 132.0cm 13b